

Moisturising lotion for every body (with Lipex L'Sens)

Raw Material	INCI Name	w/w (%)
Phase A		
Water	Aqua	ad 100,00
Phase B		
Glycerine 99,5%	Glycerin	4,00 %
Keltrol CG-SFT	Xanthan Gum	0,20
Phase C		
Akoline SL™	Sodium Stearoyl Lactylate	0,35 %
Disodium EDTA	Disodium EDTA	0,05
Phase D		
Lipex SheaLight™	Shea Butter Ethyl Esters	11,20 %
Akoline PG7™	Polyglyceryl-3 Stearate	4,50
Lipex L'sens™	Soybean Glycerides (and) Butyrospermum Parkii Butter Unsaponifiables	4,00
Lipex Bassol C™	Olus Oil	3,20
Akomed R™	Caprylic/Capric Triglycerides	1,60
Lanette O	Cetearyl Alcohol	0,80
Akoline MD50™	Glyceryl Stearate	0,50
Phase E		
Preservative	Preservative	q.s.
Phase F		
Citric Acid	Citric Acid	pH 6,2

Procedure

- 1 Prepare Phase A
- 2 Premix components of B
- 3 Add B to A while mixing
- 4 Heat to 75C
- 5 Add C to A+B
- 6 Heat Phase B to 75C and mix until melted and homogeneous
- 7 Merge phases and start mixing with medium speed
- 8 Homogenize
- 9 Cool to 30C while stirring
- 10 Add E
- 11 Adjust pH
- 12 Homogenize finally

Suitable for men and women in a broad age range. For use on entire body including hands. Contains Lipex L'Sens for instant moisturisation

The information given concerning the application and product technology represents our state of knowledge and no claims are made as to its completeness. The information given does not free the user of his own responsibility for comprehensive testing before production. We therefore disclaim any responsibility for the accuracy of the information given.

AAK Sweden AB

Personal Care
SE-374 82 Karlshamn
SWEDEN

Phone +46 454 820 00
Fax +46 454 828 85

Lipid@aak.com
www.aak.com
www.aakpersonalcare.com

Registered office: Karlshamn