

Super Smoother Body Cream

| Raw Material | INCI Name | w/w (%) |
|-------------------|--|------------|
| Phase A | | |
| Water | Aqua | ad 100 |
| Edeta BD | Disodium EDTA | 0,05 % |
| Preservative | Preservative | q.s. |
| Phase A1 | | |
| Glycerine 99,5% | Glycerin | 5,00 % |
| Keltrol CG-SFT | Xanthan Gum | 0,10 |
| Phase B | | |
| Akoline PG7™ | Polyglyceryl-3 Stearate | 3,50 % |
| Akoline SL™ | Sodium Stearoyl Lactylate | 0,35 |
| GMS | Glyceryl Stearate | 0,75 |
| Lipex SMP™ | Hydrogenated Vegetable Oil | 10,00 |
| Akomed R™ | Caprylic/Capric Triglycerides | 3,00 |
| Lipex SheaLight™ | Shea Butter Ethyl Esters | 2,00 |
| Phase C | | |
| Aristoflex AVC | Ammonium Acryloyldimethyl-taurate / VP Copolymer | 0,20 % |
| Phase D | | |
| Fragrance | Perfume | q.s. |
| Phase E | | |
| NaOH 20% in water | Sodium Hydroxide | pH 5,5-5,8 |

Procedure

- 1 Prepare Phase A
- 2 Premix phase A1 forming slurry
- 3 Add A1 to A
- 4 Prepare Phase B
- 5 Heat phases A and B separately to 75C
- 6 Homogenize
- 7 Add C to A+B
- 8 Cool to 30C while stirring
- 9 Add perfume
- 10 Adjust pH
- 11 Homogenize finally

Super Smoother Body Cream does exactly what the name suggests and more. The luxurious creamy texture is a joy to apply. Melting and spreading evenly over the skin without leaving any sticky residue. The magic touch lies in the formulation. The key ingredient is Lipex SMP which combines a silky-smooth richness with a soft-dry skin feel. Apply Super Smoother Body Cream morning and evening on freshly washed skin. Can be reapplied throughout the day to target and treat and particularly dry, rough-to-the-touch areas.

The information given concerning the application and product technology represents our state of knowledge and no claims are made as to its completeness. The information given does not free the user of his own responsibility for comprehensive testing before production. We therefore disclaim any responsibility for the accuracy of the information given.

AAK Sweden AB

Personal Care
SE-374 82 Karlshamn
SWEDEN

Phone +46 454 820 00
Fax +46 454 828 85

Lipid@aak.com
www.aak.com
www.aakpersonalcare.com

Registered office: Karlshamn