

Moisturising and smoothing lotion for seniors

Raw Material	INCI Name	w/w (%)
Phase A		
Water	Aqua	ad 100,00
Purasal Moist XS	Sodium Lactate & Sodium Gluconate	2,00 %
Genu pHresh Pectin DF	Pectin	1,00
Akoline SL™	Sodium Stearoyl Lactylate	0,75
Phase B		
Glycerine 99,5%	Glycerin	2,00 %
Keltrol CG-SFT	Xanthan Gum	0,25
Phase C		
Akoline LC™	Glyceryl Stearate Citrate	3,00 %
Akoline PG7™	Polyglyceryl-3 Stearate	2,00
Lipex L'sens™	Soybean Glycerides (and) Butyrospermum Parkii Butter Unsaponifiables	5,00
Lipex SheaLight™	Shea Butter Ethyl Esters	4,00
Lipex Bassol C™	Olus Oil	3,00
Lipex PreAct™	Canola Oil	2,00
Lipex Shea Tris™	Butyrospermum Parkii Butter Extract	0,50
Xiameter PMX-200	Dimethicone	0,75
Phase D		
Aristoflex AVC	Ammonium Acryloyldimethyl-taurate / VP Copolymer	0,25 %
Phase E		
Hydrovance	Hydroxyethyl Urea	1,00 %
Phase F		
NaOH 20% in water	Sodium Hydroxide	q.s.
Phase G		
Perfume	Perfume	0,50 %

Procedure

- 1 Prepare Phase A
- 2 Premix components of B
- 3 Add B to A while mixing
- 4 Heat to 80C
- 5 Prepare Phase B
- 6 Heat to 80C
- 7 Add C to A+B
- 8 Homogenize
- 9 Cool to 30C while stirring
- 10 Add E during stirring
- 11 Add remaining ingredients

The information given concerning the application and product technology represents our state of knowledge and no claims are made as to its completeness. The information given does not free the user of his own responsibility for comprehensive testing before production. We therefore disclaim any responsibility for the accuracy of the information given.

AAK Sweden AB

Personal Care
SE-374 82 Karlshamn
SWEDEN

Phone +46 454 820 00
Fax +46 454 828 85

Lipid@aak.com
www.aak.com
www.aakpersonalcare.com

Registered office: Karlshamn

Formulation



12 Adjust pH

13 Stir well

Rich lotion that effectively moisturises rough, dry and even flaking mature skin. Leaves distinctive layer, softening and smoothing skin. Includes actives to reinforce the skin barrier.

The information given concerning the application and product technology represents our state of knowledge and no claims are made as to its completeness. The information given does not free the user of his own responsibility for comprehensive testing before production. We therefore disclaim any responsibility for the accuracy of the information given.

AAK Sweden AB

Personal Care
SE-374 82 Karlshamn
SWEDEN

Phone +46 454 820 00
Fax +46 454 828 85

Lipid@aak.com
www.aak.com
www.aakpersonalcare.com

Registered office: Karlshamn