

## UltraGloss Lip Kiss

Raw Material	INCI Name	w/w (%)
<b>Phase A</b>		
Lipex SheaLight™	Shea Butter Ethyl Esters	ad 100
Kraton A1536	Hydrogenated styrene butadiene copolymer	10,00 %
<b>Phase B</b>		
Lipex SMP™	Hydrogenated Vegetable Oil	40,00 %
<b>Phase C</b>		
Intenza Electric Pink C91-4235	Synthetic Fluorophlogopite (and) Titanium Dioxide (and) D&C Red 28 Aluminum Lake	2,52 %
SunSHINE Ultra Glitter White C80-3800	Synthetic Fluorophlogopite (and) Titanium Dioxide	0,49
SWD 7556	Synthetic Wax (and) Titanium Dioxide	2,07

### Procedure

- 1 Disperse components of phase A
- 2 Heat phase A to 80-85 C while mixing
- 3 Melt B at 75-80C
- 4 Add B to A while mixing
- 5 Add C to A+B
- 6 Fill the packages suitable for product
- 7 Cool fast

A super-shiny lip gloss that leaves lips delectably smooth, soft and conditioned. UltraGloss Lip Kiss is a highly versatile formulation. It can be enriched with pigments to offer a sexy wash of colour, used alone, or on top of a favourite lipstick to add a seductive and sophisticated polish. Lipex SMP, together with Lipex SheaLight, forms the base of the formulation to give the unique texture and emolliency.

The information given concerning the application and product technology represents our state of knowledge and no claims are made as to its completeness. The information given does not free the user of his own responsibility for comprehensive testing before production. We therefore disclaim any responsibility for the accuracy of the information given.

**AAK Sweden AB**

Personal Care  
SE-374 82 Karlshamn  
SWEDEN

Phone +46 454 820 00  
Fax +46 454 828 85

Lipid@aak.com  
www.aak.com  
www.aakpersonalcare.com

Registered office: Karlshamn