

Formulation

AAK-18-307

Shea Innovations DermaRich Face Moisturizer

| Raw Material | INCI Name | w/w (%) |
|----------------------|---|------------|
| Phase A | | |
| Water | Aqua | ad 100 |
| Sodium Gluconate | Sodium Gluconate | 0.10 |
| Phase A1 | | |
| Glycerine 99.5% | Glycerin | 3.00 |
| Keltrol CG-SFT | Xanthan Gum | 0.15 |
| Phase B | | |
| Tego Care 450 | Polyglyceryl-3 Methylglucose Distearate | 2.00 |
| Lanette O | Cetearyl Alcohol | 2.00 |
| Lipex SheaLiquid™ TR | Butyrospermum Parkii Butter | 7.00 |
| Lipex SheaLight™ | Shea Butter Ethyl Esters | 2.00 |
| Lipex SheaTris™ | Butyrospermum Parkii Butter Extract | 1.00 |
| Lipex Collect™ | Phytosteryl Canola Glycerides | 1.00 q.s |
| Lipex PreAct™ | Canola Oil | 2.50 |
| Phase C | | |
| Preservative | Preservative | q.s. |
| Phase D | | |
| NaOH 20% in water | Sodium Hydroxide | pH 4.8–5.2 |

Procedure

1. Prepare Phase A
2. Premix A1
3. Add A1 to A while mixing
4. Prepare Phase B
5. Heat A and B separately to 75°C
6. Merge phases and start mixing with medium speed
7. Homogenize
8. Cool to 45°C while stirring
9. Add C
10. Cool to 25°C while stirring
11. Adjust pH

Our Shea Innovations DermaRich Face Moisturiser is an emulsion designed to naturally replenish lipid levels in the skin, leaving it feeling beautifully smooth, soft and comfortable. Lipex SheaLiquid TR, with its moisturising and conditioning properties, is combined with the sensory enhancing Lipex SheaLight to form the base of this nourishing, easily absorbed cream. Additional skin strengthening and soothing benefits are provided by the bioactives Lipex SheaTris and Lipex Collect.

Apply morning and evening after cleansing.

The information given concerning the application and product technology represents our state of knowledge and no claims are made as to its completeness. The information given does not free the user of his own responsibility for comprehensive testing before production. We therefore disclaim any responsibility for the accuracy of the information given.